

Delete Media Player HDMI, Delete Android Media Player Box Delete HDMI

	Amlogic T962E2
	Amlogic T962E2 Quad-Core ARM Cortex-A55
	TTTTTT ARM Mali-G31 MP2
	DDR4: 2GB/4GB
	TTTT eMMC 16G/32GB
	Android 8.1/9.0/
	WiFi IEEE 802.11ac/a/b/g/n(UWE5621DS) 2.4G/5G
	00000000000000000000000000000000000000
	5.0
	0000
	AV1 4Kx2K@75fps,VP9/H.265 8Kx4K@24fps,VP9/H.265/AVS2
	4Kx2K@60fps,H.264 4Kx2K @30fps, AVS/VC-1/MPEG-4 1080P @60fps
	H.264 1080P @30fps
	HD MPEG1/2/4,H.265/HEVC,AVS2, HD AVC/VC-1, RM/RMVB, Xvid/DivX3/4/5/6,
	RealVideo8/9/10
	Avi/Rm/Rmvb/Ts/Vob/Mkv/Mov/ISO/wmv/asf/flv/dat/mpg/mpeg MP3/WMA/AAC/WAV/OGG/DDP/TrueHD/HD/FLAC/
	HDR 10/10, Dolby Vision
DRM	Widevine (Verimatrix/Playready)
HDMI	1 * HDMI []] 1 * HDMI []]] (HDMI 2.1)
	1 *
	1 * 2.0,
	1 * USB3.0,
	UDDDD USB Flash Drive DD USB HDD
0000045	1 * 00000000000000000000000000000000000
	1 * 0000000000 TF
	0000001: 0000000 5V/2A
	CCC::: AC100-240V 50/60Hz
	;;;;;
	HD JPEG, BMP, GIF, PNG, TIF
	Miracast, DLNA, Skype, Netflix, Twitter, Picasa, Youtube, Flicker, Facebook, [][][][]
	Denonconcentration of the second seco
	Android Market, Amazon App Store []]
	TF TF TF
	4GHz []]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]]







##